

Department of Energy

§ 835.502

respiratory protective devices for protection against airborne radionuclides have been prescribed.

(b) Real-time air monitoring shall be performed as necessary to detect and provide warning of airborne radioactivity concentrations that warrant immediate action to terminate inhalation of airborne radioactive material.

[63 FR 59683, Nov. 4, 1998]

§ 835.404 [Reserved]

§ 835.405 Receipt of packages containing radioactive material.

(a) If packages containing quantities of radioactive material in excess of a Type A quantity (as defined at 10 CFR 71.4) are expected to be received from radioactive material transportation, arrangements shall be made to either:

(1) Take possession of the package when the carrier offers it for delivery; or

(2) Receive notification as soon as practicable after arrival of the package at the carrier's terminal and to take possession of the package expeditiously after receiving such notification.

(b) Upon receipt from radioactive material transportation, external surfaces of packages known to contain radioactive material shall be monitored if the package:

(1) Is labeled with a Radioactive White I, Yellow II, or Yellow III label (as specified at 49 CFR 172.403 and 172.436-440); or

(2) Has been transported as low specific activity material (as defined at 10 CFR 71.4) on an exclusive use vehicle (as defined at 10 CFR 71.4); or

(3) Has evidence of degradation, such as packages that are crushed, wet, or damaged.

(c) The monitoring required by paragraph (b) of this section shall include:

(1) Measurements of removable contamination levels, unless the package contains only special form (as defined at 10 CFR 71.4) or gaseous radioactive material; and

(2) Measurements of the radiation levels, unless the package contains less than a Type A quantity (as defined at 10 CFR 71.4) of radioactive material.

(d) The monitoring required by paragraph (b) of this section shall be completed as soon as practicable following

receipt of the package, but not later than 8 hours after the beginning of the working day following receipt of the package.

[63 FR 59683, Nov. 4, 1998]

Subpart F—Entry Control Program

§ 835.501 Radiological areas.

(a) Personnel entry control shall be maintained for each radiological area.

(b) The degree of control shall be commensurate with existing and potential radiological hazards within the area.

(c) One or more of the following methods shall be used to ensure control:

(1) Signs and barricades;

(2) Control devices on entrances;

(3) Conspicuous visual and/or audible alarms;

(4) Locked entrance ways; or

(5) Administrative controls.

(d) Written authorizations shall be required to control entry into and perform work within radiological areas. These authorizations shall specify radiation protection measures commensurate with the existing and potential hazards.

(e) No control(s) shall be installed at any radiological area exit that would prevent rapid evacuation of personnel under emergency conditions.

[58 FR 65485, Dec. 14, 1993, as amended at 63 FR 59684, Nov. 4, 1998]

§ 835.502 High and very high radiation areas.

(a) The following measures shall be implemented for each entry into a high radiation area:

(1) The area shall be monitored as necessary during access to determine the exposure rates to which the individuals are exposed; and

(2) Each individual shall be monitored by a supplemental dosimetry device or other means capable of providing an immediate estimate of the individual's integrated deep dose equivalent during the entry.

(b) *Physical controls.* One or more of the following features shall be used for each entrance or access point to a high radiation area where radiation levels