

(e) When there is an indication of swabbing or influx of formation fluids, you must take appropriate measures to control the well. You must circulate and condition the well, on or near-bottom, unless well or drilling-fluid conditions prevent running the drill pipe back to the bottom;

(f) You must calculate and post near the driller's console the maximum pressures that you may safely contain under a shut-in BOP for each casing string. The pressures posted must consider the surface pressure at which the formation at the shoe would break down, the rated working pressure of the BOP stack, and 70 percent of casing burst (or casing test as approved by the District Supervisor). As a minimum, you must post the following two pressures:

(1) The surface pressure at which the shoe would break down. This calculation must consider the current drilling fluid weight in the hole; and

(2) The lesser of the BOP's rated working pressure or 70 percent of casing-burst pressure (or casing test otherwise approved by the District Supervisor);

(g) You must install an operable drilling fluid-gas separator and degasser before you begin drilling operations. You must maintain this equipment throughout the drilling of the well;

(h) Before pulling drill-stem test tools from the hole, you must circulate or reverse-circulate the test fluids in the hole. If circulating out test fluids is not feasible, you may bullhead test fluids out of the drill-stem test string and tools with an appropriate kill weight fluid;

(i) When circulating, you must test the drilling fluid at least once each tour, or more frequently if conditions warrant. Your tests must conform to industry-accepted practices and include density, viscosity, and gel strength; hydrogenion concentration; filtration; and any other tests the District Supervisor requires for monitoring and maintaining drilling fluid quality, prevention of downhole equipment problems and for kick detection. You must record the results of these tests in the drilling fluid report; and

(j) In areas where permafrost and/or hydrate zones are present or may be present, you must control drilling fluid temperatures to drill safely through those zones.

[68 FR 8423, Feb. 20, 2003; 68 FR 14274, Mar. 24, 2003]

**§ 250.457 What equipment is required to monitor drilling fluids?**

Once you establish drilling fluid returns, you must install and maintain the following drilling fluid-system monitoring equipment throughout subsequent drilling operations. This equipment must have the following indicators on the rig floor:

(a) Pit level indicator to determine drilling fluid-pit volume gains and losses. This indicator must include both a visual and an audible warning device;

(b) Volume measuring device to accurately determine drilling fluid volumes required to fill the hole on trips;

(c) Return indicator devices that indicate the relationship between drilling fluid-return flow rate and pump discharge rate. This indicator must include both a visual and an audible warning device; and

(d) Gas-detecting equipment to monitor the drilling fluid returns. The indicator may be located in the drilling fluid-logging compartment or on the rig floor. If the indicators are only in the logging compartment, you must continually man the equipment and have a means of immediate communication with the rig floor. If the indicators are on the rig floor only, you must install an audible alarm.

[68 FR 8423, Feb. 20, 2003]

**§ 250.458 What quantities of drilling fluids are required?**

(a) You must use, maintain, and replenish quantities of drilling fluid and drilling fluid materials at the drill site as necessary to ensure well control. You must determine those quantities based on known or anticipated drilling conditions, rig storage capacity, weather conditions, and estimated time for delivery.

(b) You must record the daily inventories of drilling fluid and drilling fluid materials, including weight materials