

Minerals Management Service, Interior

§ 250.172

(b) The first year's rental as specified in § 250.1009(c)(2).

§ 250.166 If I have a State lease, what surety bond must I have for a right-of-use and easement?

(a) Before MMS issues you a right-of-use and easement on the OCS, you must furnish the Regional Director a surety bond for \$500,000.

(b) The Regional Director may require additional security from you (i.e., security above the prescribed \$500,000) to cover additional costs and liabilities for regulatory compliance. This additional surety:

(1) Must be in the form of a supplemental bond or bonds meeting the requirements of § 256.54 (General requirements for bonds) or an increase in the coverage of an existing surety bond.

(2) Covers additional costs and liabilities for regulatory compliance, including well abandonment, platform and structure removal, and site clearance from the seafloor of the right-of-use and easement.

SUSPENSIONS

§ 250.168 May operations or production be suspended?

(a) You may request approval of a suspension, or the Regional Supervisor may direct a suspension (Directed Suspension), for all or any part of a lease or unit area.

(b) Depending on the nature of the suspended activity, suspensions are labeled either Suspensions of Operations (SOO) or Suspensions of Production (SOP).

§ 250.169 What effect does suspension have on my lease?

(a) A suspension may extend the term of a lease (see § 250.180(b)). The extension is equal to the length of time the suspension is in effect, except as provided in paragraph (b) of this section.

(b) A Directed Suspension does not extend the term of a lease when the Regional Supervisor *directs* a suspension because of:

(1) Gross negligence; or

(2) A willful violation of a provision of the lease or governing statutes and regulations.

§ 250.170 How long does a suspension last?

(a) MMS may issue suspensions for up to 5 years per suspension. The Regional Supervisor will set the length of the suspension based on the conditions of the individual case involved. MMS may grant consecutive suspension periods.

(b) An SOO ends automatically when the suspended operation commences.

(c) An SOP ends automatically when production begins.

(d) A Directed Suspension normally ends as specified in the letter directing the suspension.

(e) MMS may terminate any suspension when the Regional Supervisor determines the circumstances that justified the suspension no longer exist or that other lease conditions warrant termination. The Regional Supervisor will notify you of the reasons for termination and the effective date.

§ 250.171 How do I request a suspension?

You must submit your request for a suspension to the Regional Supervisor, and MMS must receive the request before the end of the lease term (i.e., end of primary term, end of the 180-day period following the last leaseholding operation, and end of a current suspension).

(a) The justification for the suspension including the length of suspension requested;

(b) A reasonable schedule of work leading to the commencement or restoration of the suspended activity;

(c) A statement that a well has been drilled on the lease and determined to be producible according to §§ 250.115, 250.116, or 250.1603 (SOP only); and

(d) A commitment to production (SOP only).

§ 250.172 When may the Regional Supervisor grant or direct an SOO or SOP?

The Regional Supervisor may grant or direct an SOO or SOP under any of the following circumstances: