

§ 117.47

(3) The telephone number and address of the party to whom requests for openings are given.

§ 117.47 Clearance gauges.

(a) Clearance gauges are required for drawbridges across navigable waters of the United States discharging into the Atlantic Ocean south of Delaware Bay (including the Lewes and Rehoboth Canal, DE) or into the Gulf of Mexico (including coastal waterways contiguous thereto and tributaries to such waterways and the Lower Atchafalaya River, LA), except the Mississippi River and its tributaries and outlets.

(b) Except for provisions in this part which specify otherwise for particular drawbridges, clearance gauges shall be designed, installed, and maintained according to the provisions of § 118.160 of this chapter.

NOTE: Clearance gauge requirements, if any, for drawbridges other than those referred to in this section are listed in Subpart B under the appropriate bridge.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD 84-022, 51 FR 16308, May 2, 1986; CGD 96-026, 61 FR 33664, June 28, 1996]

§ 117.49 Process of violations.

(a) Complaints of alleged violations under this part are submitted to the District Commander of the Coast Guard District in which the drawbridge is located.

(b) Penalties for violations under this part are assessed and collected under Subpart 1.07 of Part 1 of this chapter.

Subpart B—Specific Requirements

§ 117.51 Purpose.

This subpart prescribes specific requirements relating to the operation of certain drawbridges.

NOTE: The drawbridges under this subpart are listed by the waterway they cross and by the state in which they are located. Waterways are arranged alphabetically by state. The drawbridges listed under a waterway are generally arranged in order from the mouth of the waterway moving upstream. The drawbridges on the Atlantic Intracoastal Waterway are listed from north to south and on the Gulf Intracoastal Waterway from east to west.

33 CFR Ch. I (7-1-04 Edition)

§ 117.53 Applicability.

(a) The requirements in this subpart apply to the bridges listed and are in addition to, or vary from, the general requirements in Subpart A.

(b) A requirement in this subpart which varies from a general requirement in Subpart A supersedes the general requirement.

(c) All other general requirements in Subpart A not at variance apply to the bridges listed in this subpart.

(d) The draws of a number of the bridges listed in this subpart need not open for the passage of vessels during certain periods, however, this does not preclude the bridge owner from directing the drawtender to open the draw during these periods.

§ 117.55 Posting of requirements.

(a) The owner of each drawbridge under this subpart, other than removable span bridges, shall ensure that a sign summarizing the requirements in this subpart applicable to the bridge is posted both upstream and downstream of the bridge. The requirements to be posted need not include those in Subpart A or §§ 117.51 through 117.99.

(b) The signs shall be of sufficient size and so located as to be easily read at any time from an approaching vessel.

(c) If advance notice is required to open the draw, the signs shall also state the name, address, and telephone number of the person to be notified.

§ 117.57 Advance notice.

Owners and tenders of drawbridges requiring advance notice to open shall use all reasonable means to open the draw at the requested time and give due regard to the possibility that a brief delay may be experienced by the vessel giving the advance notice.

§ 117.59 Special requirements due to hazards.

For the duration of occurrences hazardous to safety or navigation, such as floods, freshets, and damage to the bridge or fender system, the District Commander may require the owner of an operational drawbridge listed in this subpart to have the bridge attended full time and open on signal.

## ALABAMA

**§ 117.101 Alabama River.**

(a) The Alabama & Gulf Coast Railway Drawbridge, mile 105.3, at Coy, shall open on signal if at least 24 hours notice is given.

(b) The draw of the Canadian National/Illinois Central railroad bridge, mile 277 near Montgomery, shall open on signal if at least 24 hours notice is given.

(c) The draw of the CSX Transportation Railroad bridge, mile 293.3 near Montgomery, shall open on signal if at least 24 hours notice is given.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by USCG-2000-7223, 65 FR 40056, June 29, 2000; CGD08-03-018, 68 FR 34303, June 9, 2003; CGD08-04-001, 69 FR 5465, Feb. 5, 2004]

**§ 117.103 Bayou La Batre.**

The draw of the S188 bridge, mile 2.3 at Bayou La Batre, shall open on signal; except that, the draw need not be opened from 8 p.m. to 4 a.m. daily, and from 6:30 to 8:30 a.m. and from 2 to 5 p.m. Monday through Saturday except holidays.

[CGD8-87-11, 53 FR 5165, Feb. 22, 1988]

**§ 117.105 Bayou Sara.**

The draw of the CSX Transportation Railroad bridge, mile 0.1 near Saraland, shall open on signal; except that, from 6 p.m. to 10 a.m. the draw shall open on signal if at least eight hours notice is given. During periods of severe storms or hurricanes, from the time the National Weather Service sounds an "alert" for the area until the "all clear" is sounded, the draw shall open on signal.

[CGD8-85-12, 50 FR 41685, Oct. 15, 1985]

**§ 117.107 Chattahoochee River.**

The draws of the CSX Transportation Railroad bridge, mile 117.1 near Omaha, GA, shall open on signal if at least six hours notice is given.

**§ 117.109 Coosa River.**

The draw of the CSX Transportation Railroad bridge, mile 175.0 at Gadsden, shall open on signal if at least six hours notice is given.

**§ 117.113 Tensaw River.**

The draw of the CSX Transportation Railroad bridge, mile 15.0 at Hurricane, shall open on signal; except that, from 5 p.m. to 9 a.m., the draw shall open on signal if at least eight hours notice is given. During periods of severe storms or hurricanes, from the time the National Weather Service sounds an "alert" for the area until the "all clear" is sounded, the draw shall open on signal.

[CGD8-85-09, 50 FR 37356, Sept. 13, 1985]

**§ 117.115 Three Mile Creek.**

(a) The draw of the US43 bridge, mile 1.0 at Mobile, need not be opened from 7 a.m. to 9 a.m. and from 4:30 p.m. to 6:30 p.m. daily. At all other times, the draw shall open on signal if at least 12 hours notice is given.

(b) The draw of the Norfolk Southern railroad bridge, mile 1.1 at Mobile, shall open on signal if at least five days notice is given.

## ARKANSAS

**§ 117.121 Arkansas River**

The draw of the Missouri Pacific Railroad bridge, mile 23.1 near Yancopin, shall open on signal if at least 96 hours notice is given.

**§ 117.123 Arkansas Waterway-Automated Railroad Bridges.**

(a) Across the Arkansas River, the draw of the Cotton Belt Railroad (Rob Roy) Bridge, Mile 67.4, is maintained in the closed position and is remotely operated. The following signals shall be used:

(1) The opening signal from the vessel for each of these bridges is three short blasts.

(2) The acknowledging signal is flashing white lights visible upstream and downstream. When the operator of the vessel sights the acknowledging signal, one prolonged blast shall be sounded.

(3) This signal is acknowledged by the bridge controller when the draw is to open by changing the flashing white lights to continuous white lights, and sounding one blast on a horn. When the span is fully raised to a maximum clearance of 52 feet, the navigation lights at mid channel change from red