

the coking time for the oven to the coking time specified in the written plan for the observed flue temperature before pushing the oven. The oven must continue to operate at this coking time (or at a longer coking time if the temperature falls below the minimum allowed for the increased coking time) until the problem has been corrected, and you have confirmed that the corrective action was successful as required by paragraph (a)(4)(v) of this section.

(v) Once the heating problem has been corrected, the oven may be returned to the battery's normal coking schedule. You must then measure and record the flue temperatures for the oven within 2 hours before the scheduled pushing time for the next two consecutive pushes. If any flue temperature measurement is below the minimum flue temperature for that coking time established in the written plan, repeat the procedures in paragraphs (a)(4)(iii) and (iv) of this section.

(vi) If any flue temperature measurement is below the battery-wide minimum acceptable temperature for complete coking established in the written plan for any oven at any coking time, you must remove the oven from service for repairs.

(vii) For an oven that has been repaired and returned to service after being removed from service in accordance with paragraph (a)(4)(vi) of this section, you must measure and record the temperatures of all flues for the oven within 2 hours before the first scheduled pushing time. If any flue temperature measurement is below the minimum flue temperature for the scheduled coking time, as established in the written plan, you must repeat the procedures described in paragraphs (a)(4)(iii) and (iv) of this section.

(viii) For an oven that has been repaired and returned to service after removal from service in accordance with paragraph (a)(4)(vi) of this section, you must report as a deviation to the permitting authority any flue temperature measurement made during the initial coking cycle after return to service that is below the lowest acceptable minimum flue temperature.

(b) As provided in §63.6(g), you may request to use an alternative to the

work practice standards in paragraph (a) of this section.

§ 63.7293 What work practice standards must I meet for fugitive pushing emissions if I have a non-recovery coke oven battery?

(a) You must meet the requirements in paragraphs (a)(1) and (2) of this section for each new and existing non-recovery coke oven battery.

(1) You must visually inspect each oven prior to pushing by opening the door damper and observing the bed of coke.

(2) Do not push the oven unless the visual inspection indicates that there is no smoke in the open space above the coke bed and that there is an unobstructed view of the door on the opposite side of the oven.

(b) As provided in §63.6(g), you may request to use an alternative to the work practice standard in paragraph (a) of this section.

§ 63.7294 What work practice standard must I meet for soaking?

(a) For each new and existing by-product coke oven battery, you must prepare and operate at all times according to a written work practice plan for soaking. Each plan must include measures and procedures to:

(1) Train topside workers to identify soaking emissions that require corrective actions.

(2) Damper the oven off the collecting main prior to opening the standpipe cap.

(3) Determine the cause of soaking emissions that do not ignite automatically, including emissions that result from raw coke oven gas leaking from the collecting main through the damper, and emissions that result from incomplete coking.

(4) If soaking emissions are caused by leaks from the collecting main, take corrective actions to eliminate the soaking emissions. Corrective actions may include, but are not limited to, re-seating the damper, cleaning the flushing liquor piping, using aspiration, putting the oven back on the collecting main, or igniting the emissions.

(5) If soaking emissions are not caused by leaks from the collecting main, notify a designated responsible

party. The responsible party must determine whether the soaking emissions are due to incomplete coking. If incomplete coking is the cause of the soaking emissions, you must put the oven back on the collecting main until it is completely coked or you must ignite the emissions.

(b) As provided in §63.6(g), you may request to use an alternative to the work practice standard in paragraph (a) of this section.

§ 63.7295 What requirements must I meet for quenching?

(a) You must meet the requirements in paragraphs (a)(1) and (2) of this section for each quench tower and backup quench station at a new or existing coke oven battery.

(1) For the quenching of hot coke, you must meet the requirements in paragraph (a)(1)(i) or (ii) of this section.

(i) The concentration of total dissolved solids (TDS) in the water used for quenching must not exceed 1,100 milligrams per liter (mg/L); or

(ii) The sum of the concentrations of benzene, benzo(a)pyrene, and naphthalene in the water used for quenching must not exceed the applicable site-specific limit approved by the permitting authority.

(2) You must use acceptable makeup water, as defined in §63.7352, as makeup water for quenching.

(b) For each quench tower at a new or existing coke oven battery and each backup quench station at a new coke oven battery, you must meet each of the requirements in paragraphs (b)(1) through (4) of this section.

(1) You must equip each quench tower with baffles such that no more than 5 percent of the cross sectional area of the tower may be uncovered or open to the sky.

(2) You must wash the baffles in each quench tower once each day that the tower is used to quench coke, except as specified in paragraphs (b)(2)(i) and (ii) of this section.

(i) You are not required to wash the baffles in a quench tower if the highest measured ambient temperature remains less than 30 degrees Fahrenheit throughout that day (24-hour period). If the measured ambient temperature

rises to 30 degrees Fahrenheit or more during the day, you must resume daily washing according to the schedule in your operation and maintenance plan.

(ii) You must continuously record the ambient temperature on days that the baffles were not washed.

(3) You must inspect each quench tower monthly for damaged or missing baffles and blockage.

(4) You must initiate repair or replacement of damaged or missing baffles within 30 days and complete as soon as practicable.

(c) As provided in §63.6(g), you may request to use an alternative to the work practice standards in paragraph (b) of this section.

§ 63.7296 What emission limitations must I meet for battery stacks?

You must not discharge to the atmosphere any emissions from any battery stack at a new or existing by-product coke oven battery that exhibit an opacity greater than the applicable limit in paragraphs (a) and (b) of this section.

(a) Daily average of 15 percent opacity for a battery on a normal coking cycle.

(b) Daily average of 20 percent opacity for a battery on batterywide extended coking.

OPERATION AND MAINTENANCE
REQUIREMENTS

§ 63.7300 What are my operation and maintenance requirements?

(a) As required by §63.6(e)(1)(i), you must always operate and maintain your affected source, including air pollution control and monitoring equipment, in a manner consistent with good air pollution control practices for minimizing emissions at least to the levels required by this subpart.

(b) You must prepare and operate at all times according to a written operation and maintenance plan for the general operation and maintenance of new or existing by-product coke oven batteries. Each plan must address, at a minimum, the elements listed in paragraphs (b)(1) through (6) of this section.

(1) Frequency and method of recording underfiring gas parameters.