

§22.571

47 CFR Ch. I (10-1-05 Edition)

and addition radials above and below the below the inter-station radial at 2.5° intervals.

(f) *UHF interfering contour.* For base and fixed stations transmitting on the UHF channels, the radial distance from the transmitting antenna to the interfering contour along each cardinal radial is calculated as follows:

(1) If the radial antenna HAAT is less than 150 meters:

d=9.471×h<sup>0.23</sup>×p<sup>0.15</sup>

where:

d is the radial distance in kilometers  
h is the radial antenna HAAT in meters  
p is the radial ERP in Watts

Whenever the actual HAAT is less than 30 meters (98 feet), 30 must be used as the value for h in the above formula.

(2) If the radial antenna HAAT is 150 meters or more:

d=6.336×h<sup>0.31</sup>×p<sup>0.15</sup>

where:

d is the radial distance in kilometers  
h is the radial antenna HAAT in meters  
p is the radial ERP in Watts

(3) The value used for p in the above formula must not be less than 27 dB less than the maximum ERP in any direction, or 0.1 Watt, whichever is more.

(4) The distance from the transmitting antenna to the interfering contour along any radial other than the eight cardinal radials is routinely calculated by linear interpolation of distance as a function of angle. However, in resolving petitions to deny, the FCC may calculate the distance to the interfering contour using the appropriate formula in paragraph (f) of this section with actual HAAT and ERP data for the inter-station radial and additional radials above and below the inter-station radial at 2.5° intervals.

(g) *Protection for BETRS.* In applying the provisions of paragraph (a) of this section, if either or both of the transmitters involved is a BETRS central office station, the following contour substitutions must be used:

(1) The service contour of the BETRS central office station(s) is a circle, centered on the central office station antenna, with a radius of 40 kilometers (25 miles).

(2) The interfering contour of any station of any type, when determining whether it would overlap the service contour of a BETRS central office station, is calculated as follows:

d=36.364×h<sup>0.2</sup>× p<sup>0.1</sup>

where:

d is the radial distance in kilometers  
h is the radial antenna HAAT in meters  
p is the radial ERP in Watts

Whenever the actual HAAT is less than 30 meters (98 feet), 30 must be used as the value for h in the above formula. The value used for p in the above formula must not be less than 27 dB less than the maximum ERP in any direction, or 0.1 Watt, whichever is more.

(h) *Assignment of mobile channels to base or fixed transmitters.* Mobile channels may be assigned to base or fixed transmitters if the following criteria are met:

(1) The paired base channel, as designated in §22.561, is assigned to base transmitters in the same geographical area operated by the same licensee.

(2) The authorization is granted subject to the condition that no interference be caused to fixed receivers in use on or prior to the date of the grant.

§22.571 Responsibility for mobile stations.

Mobile stations that are subscribers in good standing to a two-way service in the Paging and Radiotelephone Service, when receiving service from that station, are considered to be operating under the authorization of that station. Licensees are responsible for exercising effective operational control over mobile stations receiving service through their stations. Mobile stations that are subscribers in good standing to a two-way service in the Paging and Radiotelephone Service, while receiving service from a different station, are considered to be operating under the authorization of such different station. The licensee of such different station is responsible, during such temporary period, for exercising effective operational control over such mobile stations as if they were subscribers to it.