

(c) No person may deactivate a ground proximity warning system required by this section except in accordance with the procedures contained in the Airplane Flight Manual.

(d) Whenever a ground proximity warning system required by this section is deactivated, an entry shall be made in the airplane maintenance record that includes the date and time of deactivation.

(e) No person may operate a turbine-powered airplane unless it is equipped with a ground proximity warning/glide slope deviation alerting system that meets the performance and environmental standards contained in TSO-C92a or TSO-C92b or incorporates TSO-approved ground proximity warning-glide slope deviation alerting equipment.

(f) No person may operate a turbojet powered airplane equipped with a system required by paragraph (e) of this section, that incorporates equipment that meets the performance and environmental standards of TSO-C92b or is approved under that TSO, using other than Warning Envelopes 1 or 3 for Warning Modes 1 and 4.

(g) This section expires on March 29, 2005.

[Doc. No. 28154, 60 FR 65933, Dec. 20, 1995, as amended by Amdt. 121-273, 65 FR 16755, Mar. 29, 2000]

Subpart L—Maintenance, Preventive Maintenance, and Alterations

SOURCE: Docket No. 6258, 29 FR 19210, Dec. 31, 1964, unless otherwise noted.

§ 121.361 Applicability.

(a) Except as provided by paragraph (b) of this section, this subpart prescribes requirements for maintenance, preventive maintenance, and alterations for all certificate holders.

(b) The Administrator may amend a certificate holder’s operations specifications to permit deviation from those provisions of this subpart that would prevent the return to service and use of airframe components, powerplants, appliances, and spare parts thereof because those items have been maintained, altered, or inspected by

persons employed outside the United States who do not hold U.S. airman certificates. Each certificate holder who uses parts under this deviation must provide for surveillance of facilities and practices to assure that all work performed on these parts is accomplished in accordance with the certificate holder’s manual.

[Doc. No. 8754, 33 FR 14406, Sept. 25, 1968]

§ 121.363 Responsibility for airworthiness.

(a) Each certificate holder is primarily responsible for—

(1) The airworthiness of its aircraft, including airframes, aircraft engines, propellers, appliances, and parts thereof; and

(2) The performance of the maintenance, preventive maintenance, and alteration of its aircraft, including airframes, aircraft engines, propellers, appliances, emergency equipment, and parts thereof, in accordance with its manual and the regulations of this chapter.

(b) A certificate holder may make arrangements with another person for the performance of any maintenance, preventive maintenance, or alterations. However, this does not relieve the certificate holder of the responsibility specified in paragraph (a) of this section.

[Doc. No. 6258, 29 FR 19210, Dec. 31, 1964, as amended by Amdt. 121-106, 38 FR 22378, Aug. 20, 1973]

§ 121.365 Maintenance, preventive maintenance, and alteration organization.

(a) Each certificate holder that performs any of its maintenance (other than required inspections), preventive maintenance, or alterations, and each person with whom it arranges for the performance of that work must have an organization adequate to perform the work.

(b) Each certificate holder that performs any inspections required by its manual in accordance with § 121.369(b)(2) or (3) (in this subpart referred to as *required inspections*) and each person with whom it arranges for the performance of that work must have an organization adequate to perform that work.