

§266.411

40 CFR Ch. I (7-1-07 Edition)

and on the warning statement. It shall sign and date the USFRS Transportation Tracking Document for each shipment of USFRS XL waste it transports and carry it with each shipment that it carries. It shall carry the USFRS XL waste MSDS with each shipment. It shall pick up each shipment of USFRS XL waste prior to the expiration of the storage time limit provided the generator pursuant to §266.408. It shall deliver each shipment of USFRS XL waste to the USFRS Roseville, Minnesota facility located at 2430 Rose Place within 30 days of it being picked-up at a USFRS XL waste generator. A USFRS transporter may store USFRS XL waste for no more than 10 days at a transfer facility without being subject to regulation under 40 CFR parts 264, 265, 268 and 270 for the storage of those wastes.

§266.411 Releases of USFRS XL waste during transport.

In the event of a release of USFRS XL waste during transportation, a USFRS XL waste transporter must take appropriate immediate action to protect human health and the environment, including preventing the spilled material from entering a water system or a water body. The USFRS XL waste transporter also must comply with the provisions of 40 CFR 263.31. The USFRS XL waste transporter will contact USFRS and the nearest police, public safety authority, EPA or MPCA, provide any emergency responder with a copy of the USFRS XL waste MSDS, handle the spilled material in accordance with the USFRS XL waste MSDS and the direction of any governmental entity charged with emergency response authority and transport any spilled USFRS XL waste and contaminated soils or equipment to the USFRS facility located at 2430 Rose Place, Roseville, Minnesota in an appropriately sized polycontainer.

§266.412 USFRS XL waste generator closure.

(a) *Generator responsibilities.* At the time of termination of a USFRS XL generator's participation in the USFRS XL Project, the USFRS XL waste generator will disconnect its process(es) from the water treatment resin can-

isters and filter containers; implement the alternative treatment or disposal required by §266.413; arrange for the transport to USFRS of all USFRS XL waste that it has in storage; decontaminate any contamination resulting from the storage or handling of USFRS XL waste; and document its efforts to comply with this closure requirement.

(b) *USFRS responsibilities.* Prior to termination of a USFRS XL waste generator's participation in the USFRS XL Waste Project USFRS will remove all of the USFRS XL waste in the generator's storage area. USFRS will inspect the USFRS XL waste generator to determine if all USFRS XL wastes have been removed and to document the condition of the USFRS XL waste storage area. USFRS will provide a written summary to the customer, EPA, MPCA and as appropriate the County Agencies of its evaluation pursuant to this paragraph (b).

§266.413 USFRS XL waste generator requirements to maintain alternate treatment or disposal capacity.

During the period that it is participating in the USFRS XL waste Project, a USFRS XL waste generator shall maintain the ability to legally treat or dispose of its process wastes contributing to the USFRS XL waste by methods other than through transportation and treatment to USFRS' Roseville, Minnesota facility. A USFRS XL waste generator may use this alternative treatment or disposal method only after its participation in this XL Project has been terminated.

§266.414 Termination of a USFRS XL waste approved customer's participation in the USFRS XL Project.

The provisions in this section apply to a USFRS XL waste approved customer who has not yet generated USFRS XL waste. If a USFRS XL waste approved customer has generated or first caused to be regulated USFRS XL waste, then it is a USFRS XL waste generator and must comply with the termination provisions contained in §266.415. The following procedures are to be followed to terminate a person's participation in the federal USFRS XL Project. MPCA or the County Agencies