

## CONTINUOUS COMPLIANCE REQUIREMENTS

**§ 63.8810 How do I monitor and collect data to demonstrate continuous compliance?**

(a) If you own or operate a loop slitter adhesive use affected source, you must meet the requirements in paragraphs (a)(1) and (2) of this section.

(1) Maintain a list of each adhesive and the manufacturer or supplier of each.

(2) Maintain a record of EPA Method 311 (appendix A to 40 CFR part 63), approved alternative method, or other reasonable means of HAP content determinations indicating the mass percent of each HAP for each adhesive.

(b) If you own or operate a new or reconstructed flame lamination affected source, you must meet the requirements in paragraphs (b)(1) through (3) of this section if you use a scrubber, or paragraph (b)(4) of this section if you use any other control device.

(1) Keep records of the daily average scrubber inlet liquid flow rate.

(2) Keep records of the daily average scrubber effluent pH.

(3) If you use a venturi scrubber, keep records of daily average pressure drop across the venturi.

(4) Keep records of operating parameter values for each operating parameter that applies to you.

(c) If you own or operate a new or reconstructed flame lamination affected source, you must meet the requirements in paragraphs (c)(1) through (4) of this section.

(1) Except for periods of monitoring malfunctions, associated repairs, and required quality assurance or control activities (including, as applicable, calibration checks and required zero and span adjustments), you must monitor continuously (or collect data at all required intervals) at all times that the affected source is operating. This includes periods of startup, shutdown, and malfunction when the affected source is operating. A monitoring malfunction includes, but is not limited to, any sudden, infrequent, not reasonably preventable failure of the monitoring device to provide valid data. Monitoring failures that are caused by poor maintenance or careless operation are not malfunctions.

(2) In data average calculations and calculations used to report emission or operating levels, you may not use data recorded during monitoring malfunctions, associated repairs, or recorded during required quality assurance or control activities. Nor may such data be used in fulfilling any applicable minimum data availability requirement. You must use all the data collected during all other periods in assessing the operation of the control device and associated control system.

(3) You must conduct a performance evaluation of each CMS in accordance with your site-specific monitoring plan.

(4) You must operate and maintain the CMS in continuous operation according to the site-specific monitoring plan.

**§ 63.8812 How do I demonstrate continuous compliance with the emission limitations?**

(a) You must demonstrate continuous compliance with each emission limit and operating limit in Tables 1 and 2 to this subpart that applies to you according to the methods specified in Table 5 to this subpart.

(b) You must report each instance in which you did not meet each emission limit and each operating limit in Tables 1 and 2 to this subpart that apply to you. For new or reconstructed flame lamination affected sources, this includes periods of startup, shutdown, and malfunction. These instances are deviations from the operating limits in this subpart. These deviations must be reported according to the requirements in § 63.8818.

(c) [Reserved]

(d) Consistent with §§ 63.6(e) and 63.7(e)(1), deviations that occur at a new or reconstructed flame lamination affected source during a period of startup, shutdown, or malfunction are not violations if you demonstrate to the Administrator's satisfaction that you were operating in accordance with § 63.6(e)(1). The Administrator will determine whether deviations that occur at a new or reconstructed flame lamination affected source during a period of startup, shutdown, or malfunction are violations, according to the provisions in § 63.6(e).