§ 90.422

probe, but sufficiently distant (radially) from other probes and the tunnel wall so as to be free from the influences of any wakes or eddies.

- (B) The sample probe for continously intergrated NO_X , CO, and CO_2 must be heated and insulated over the entire length, to prevent water condensation, to a minimum temperature of 55 °C. Sample gas temperature immediately before the first filter in the system must be at least 55 °C.
- (ii) Conform to the continuous NO_X , CO, or CO_2 sampling and analysis system to the specifications of part 86, subpart D of this chapter with the following exceptions and revisions:
- (A) Heat the system components requiring heating only to prevent water condensation, the minimum component temperature is 55 $^{\circ}\text{C}.$
- (B) Coordinate analysis system response time with CVS flow fluctuations and sampling time/test cycle offsets, if necessary.
- (C) Use only analytical gases conforming to the specifications of §90.312 of this subpart for calibration, zero and span checks.
- (D) Use a calibration curve conforming to $\S 90.321$ for CO and CO₂ and $\S 90.318$ for NO_X for any range on a linear analyzer below 155 ppm.
- (iii) Convert the chart deflections or voltage output of analyzers with non-linear calibration curves to concentration values by the calibration curve(s) specified in §90.321 of this chapter before flow correction (if used) and subsequent integration takes place.

§ 90.422 Background sample.

- (a) Background samples are produced by drawing a sample of the dilution air during the exhaust collection phase of each test cycle mode.
- (1) An individual background sample may be produced and analyzed for each mode. Hence, a unique background value will be used for the emission calculations for each mode.
- (2) Alternatively, a single background sample may be produced by drawing a sample during the collection phase of each test cycle mode. Hence, a single cumulative background value will be used for the emission calculations for each mode.

- (b) For analysis of the individual sample described in paragraph (a)(1) of this section, a single value representing the average chart deflection over a 10-second stabilized period must be stored. All readings taken during the data logging period must be stable within \pm one percent of full scale.
- (c) Measure HC, CO, CO_2 , and NO_X exhaust and background concentrations in the sample bag(s) with approximately the same flow rates and pressures used during calibration.

§ 90.423 Exhaust gas analytical system; CVS grab sample.

- (a) Schematic drawings. Figure 4 in Appendix B of this subpart is a schematic drawing of the exhaust gas analytical systems used for analyzing CVS grab "bag" samples from spark-ignition engines. Since various configurations can produce accurate results, exact conformance with the drawing is not required. Additional components such as instruments, valves, solenoids, pumps and switches may be used to provide additional information and coordinate the functions of the component systems. Other components such as snubbers, which are not needed to maintain accuracy in some systems, may be excluded if their exclusion is based upon good engineering judgment.
- (b) Major component description. The analytical system, Figure 4 in Appendix B of this subpart, consists of a flame ionization detector (FID) or a heated flame ionization detector (HFID) for the measurement of hydrocarbons, non-dispersive infrared analyzers (NDIR) for the measurement of carbon monoxide and carbon dioxide, and a chemiluminescence detector (CLD) (or heated CLD (HCLD)) for the measurement of oxides of nitrogen. The exhaust gas analytical system must conform to the following requirements:
- (1) The CLD (or HCLD) requires that the nitrogen dioxide present in the sample be converted to nitric oxide before analysis. Other types of analyzers may be used if shown to yield equivalent results and if approved in advance by the Administrator.
- (2) If CO instruments are used which are essentially free of CO_2 and water