

your ability to show that engines comply with all applicable emission standards.

**§ 1065.378 NO<sub>2</sub>-to-NO converter conversion verification.**

(a) *Scope and frequency.* If you use an analyzer that measures only NO to determine NO<sub>x</sub>, you must use an NO<sub>2</sub>-to-NO converter upstream of the analyzer. Perform this verification after installing the converter, after major maintenance and within 35 days before an emission test. This verification must be repeated at this frequency to verify that the catalytic activity of the NO<sub>2</sub>-to-NO converter has not deteriorated.

(b) *Measurement principles.* An NO<sub>2</sub>-to-NO converter allows an analyzer that measures only NO to determine total NO<sub>x</sub> by converting the NO<sub>2</sub> in exhaust to NO.

(c) *System requirements.* An NO<sub>2</sub>-to-NO converter must allow for measuring at least 95% of the total NO<sub>2</sub> at the maximum expected concentration of NO<sub>2</sub>.

(d) *Procedure.* Use the following procedure to verify the performance of a NO<sub>2</sub>-to-NO converter:

(1) *Instrument setup.* Follow the analyzer and NO<sub>2</sub>-to-NO converter manufacturers' start-up and operating instructions. Adjust the analyzer and converter as needed to optimize performance.

(2) *Equipment setup.* Connect an ozonator's inlet to a zero-air or oxygen source and connect its outlet to one port of a 4-way cross fitting. Connect an NO span gas to another port. Connect the NO<sub>2</sub>-to-NO converter inlet to another port, and connect an overflow vent line to the last port.

(3) *Adjustments.* Take the following steps to make adjustments:

(i) With the NO<sub>2</sub>-to-NO converter in the bypass mode (i.e., NO mode) and the ozonator off, adjust the NO and zero-gas flows so the NO concentration at the analyzer is at the peak total NO<sub>x</sub> concentration expected during testing. Verify that gas is flowing out of the overflow vent.

(ii) With the NO<sub>2</sub>-to-NO converter still in the bypass mode, turn on the ozonator and adjust the ozonator so the NO concentration measured by the analyzer decreases by the same amount as maximum concentration of NO<sub>2</sub> ex-

pected during testing. This ensures that the ozonator is generating NO<sub>2</sub> at the maximum concentration expected during testing.

(4) *Data collection.* Maintain the ozonator adjustment in paragraph (d)(3) of this section, and keep the NO<sub>x</sub> analyzer in the NO only mode (i.e., bypass the NO<sub>2</sub>-to-NO converter).

(i) Allow for stabilization, accounting only for transport delays and instrument response.

(ii) Calculate the mean of 30 seconds of sampled data from the analyzer and record this value as NO<sub>ref</sub>.

(iii) Switch the analyzer to the total NO<sub>x</sub> mode (that is, sample with the NO<sub>2</sub>-to-NO converter) and allow for stabilization, accounting only for transport delays and instrument response.

(iv) Calculate the mean of 30 seconds of sampled data from the analyzer and record this value as NO<sub>xmeas</sub>.

(v) Turn off the ozonator and allow for stabilization, accounting only for transport delays and instrument response.

(vi) Calculate the mean of 30 seconds of sampled data from the analyzer and record this value as NO<sub>xref</sub>.

(5) *Performance evaluation.* Divide the quantity of (NO<sub>xmeas</sub> - NO<sub>ref</sub>) by the quantity of (NO<sub>xref</sub> - NO<sub>ref</sub>). If the result is less than 95%, repair or replace the NO<sub>2</sub>-to-NO converter.

(e) *Exceptions.* The following exceptions apply:

(1) You may omit this verification if you can show by engineering analysis that for your NO<sub>x</sub> sampling system and your emission calculations procedures, the converter always affects your brake-specific NO<sub>x</sub> emission results by less than 0.5% of the applicable NO<sub>x</sub> standard.

(2) You may use a converter that you determine does not meet this verification, as long as you try to correct the problem and the measurement deficiency does not adversely affect your ability to show that engines comply with all applicable emission standards.

PM MEASUREMENTS

**§ 1065.390 PM balance verifications and weighing process verification.**

(a) *Scope and frequency.* This section describes three verifications. The first

verification requires an independent verification of PM balance performance, and this must be performed within 370 days before emission testing. The second verification requires zeroing and spanning the balance, and this must be performed within 12 h before weighing. The third verification requires comparing a current mass determination of pooled reference samples with the previous mass determination of the pooled reference samples. This verification must be performed within 12 h before weighing.

(b) *Independent verification.* Have the balance manufacturer (or a representative approved by the balance manufacturer) verify the balance performance within 370 days of testing.

(c) *Zeroing and spanning.* You must verify balance performance by zeroing and spanning it with at least one calibration weight, and any weights you use must meet the specifications in § 1065.790 to perform this verification.

(1) Use a manual procedure in which you zero the balance and span the balance with at least one calibration weight. If you normally use mean values by repeating the weighing process to improve the accuracy and precision of PM measurements, use the same process to verify balance performance.

(2) You may use an automated procedure to verify balance performance. For example many balances have internal calibration weights that are used automatically to verify balance performance. Note that if you use internal balance weights, the weights must meet the specifications in § 1065.790 to perform this verification.

(d) *Reference sample weighing.* You must also verify the PM-weighing environment and weighing process by weighing reference PM sample media. Repeated weighing of a reference mass must return the same value within  $\pm 10$   $\mu$ g or  $\pm 10\%$  of the net PM mass expected at the standard (if known), whichever is higher. Perform this verification as follows:

(1) Keep at least two samples of unused PM sample media in the PM-stabilization environment. Use these as references. If you collect PM with filters, select unused filters of the same material and size for use as references.

You may periodically replace references, using good engineering judgment.

(2) Stabilize references in the PM stabilization environment. Consider references stabilized if they have been in the PM-stabilization environment for a minimum of 30 min, and the PM-stabilization environment has been within the specifications of § 1065.190(d) for at least the preceding 60 min.

(3) Exercise the balance several times with a reference sample. We recommend weighing ten samples without recording the values.

(4) Zero and span the balance.

(5) Weigh each of the reference samples and record their masses. We recommend using substitution weighing as described in § 1065.590(j). If you normally use mean values by repeating the weighing process to improve the accuracy and precision of PM measurements, use the same process to measure reference masses.

(6) Record the balance environment dewpoint, ambient temperature, and atmospheric pressure.

(7) Use the recorded ambient conditions to correct results for buoyancy as described in § 1065.690. Record the buoyancy-corrected mass of each of the references.

(8) Subtract each of the reference's buoyancy-corrected masses from the most recent previous determinations of their masses.

(9) If the mean of the reference's masses changes by more than that allowed under paragraph (d) of this section, then invalidate all PM results that were determined between the two times that the reference masses were determined.

#### **§ 1065.395 Inertial PM balance verifications.**

This section describes how to verify the performance of an inertial PM balance.

(a) *Independent verification.* Have the balance manufacturer (or a representative approved by the balance manufacturer) verify the inertial balance performance within 370 days before testing.

(b) *Other verifications.* Perform other verifications using good engineering