

**§ 76.13**

following the day on which the extension approved under paragraph (e)(3) of this section terminates. Compliance shall be determined as specified in part 75 of this chapter using measured values of NO<sub>x</sub> emissions and heat input only for the portion of the year that the emission limit is in effect. If a unit with an approved extension is included in an averaging plan under § 76.11 for year 1997, the unit shall be treated, for the purpose of applying Equation 1 in § 76.11(a)(6) and Equation 2 in § 76.11(d)(1)(ii)(A), as subject to the applicable emission limitation under § 76.5 for the entire year 1997.

**§ 76.13 Compliance and excess emissions.**

Excess emissions of nitrogen oxides under § 77.6 of this chapter shall be calculated as follows:

(a) For a unit that is not in an approved averaging plan:

(1) Calculate EE<sub>i</sub> for each portion of the calendar year that the unit is subject to a different NO<sub>x</sub> emission limitation:

$$EE_i = \frac{(R_{ai} - R_{li}) \times HI_i}{2000} \quad (\text{Equation 3})$$

where:

EE<sub>i</sub> = Excess emissions for NO<sub>x</sub> for the portion of the calendar year (in tons);

$$EE = \frac{\sum_{i=1}^n (R_{ai} \times HI_i) - \sum_{i=1}^n (R_{li} \times HI_i)}{2000} \quad (\text{Equation 5})$$

where:

EE = Excess emissions for NO<sub>x</sub> for the year (in tons);

R<sub>ai</sub> = Actual annual average emission rate for NO<sub>x</sub> for unit i, (in lb/mmBtu), determined according to part 75 of this chapter;

R<sub>li</sub> = Applicable emission limitation for unit i, (in lb/mmBtu), as specified in § 76.5, 76.6, or 76.7;

HI<sub>i</sub> = Actual annual heat input for unit i, mmBtu, determined according to part 75 of this chapter;

n = Number of units in the averaging plan.

**40 CFR Ch. I (7-1-03 Edition)**

R<sub>ai</sub> = Actual average emission rate for the unit (in lb/mmBtu), determined according to part 75 of this chapter for the portion of the calendar year for which the applicable emission limitation R<sub>i</sub> is in effect;

R<sub>li</sub> = Applicable emission limitation for the unit, (in lb/mmBtu), as specified in § 76.5, 76.6, or 76.7 or as determined under § 76.10;

$$EE = \sum_{i=1}^n EE_i \quad (\text{Equation 4})$$

HI<sub>i</sub> = Actual heat input for the unit, (in mmBtu), determined according to part 75 of this chapter for the portion of the calendar year for which the applicable emission limitation, R<sub>i</sub>, is in effect.

(2) If EE<sub>i</sub> is a negative number for any portion of the calendar year, the EE value for that portion of the calendar year shall be equal to zero (e.g., if EE<sub>i</sub> = -100, then EE<sub>i</sub> = 0).

(3) Sum all EE<sub>i</sub> values for the calendar year:

where:

EE = Excess emissions for NO<sub>x</sub> for the year (in tons);

n = The number of time periods during which a unit is subject to different emission limitations; and

(b) For units participating in an approved averaging plan, when all the requirements under § 76.11(d)(1) are not met,

**§ 76.14 Monitoring, recordkeeping, and reporting.**

(a) A petition for an alternative emission limitation demonstration period under § 76.10(d) shall include the following information:

(1) In accordance with § 76.10(d)(4), the following information:

(i) Documentation that the owner or operator solicited bids for a NO<sub>x</sub> emission control system designed for application to the specific boiler and designed to achieve the applicable emission limitation in § 76.5, 76.6, or 76.7 on